This section gives you tips on starting the engine under various conditions, and how to operate the 5-speed manual and automatic transmissions. It also includes important information on parking your car, the braking system, and facts you need if you are planning to tow a trailer.

Preparing to Drive..... 170
Starting the Engine..... 171
Starting in Cold Weather at High Altitude 172
5-speed Manual Transmission..... 172
Recommended Shift Points..... 173
Maximum Allowable Speeds.... 174
Automatic Transmission..... 174
Shift Lever Position Indicator.. 175
Shift Lever Positions..... 175
Maximum Allowable Speeds.... 178
Shift Lock Release..... 178
Parking..... 180
The Braking System..... 181
Brake Wear Indicators..... 181
Brake System Design..... 182
Anti-lock Brakes..... 182
Important Safety Reminders..... 183
ABS Indicator..... 183
Driving in Bad Weather..... 184
Towing a Trailer..... 186